

SAGAN *Life*™

RV WATER FILTER KIT



ASSEMBLY & USE INSTRUCTIONS

Make sure the 2 brass fittings in the housing already are tightly in place. Remove plastic from filter (1) and insert filter into the housing (2). Note: the protruding circle on the inside of the cap and housing should fit inside the center hole of the filter.

Screw the housing cap on the housing making sure the protruding circle in the center of the cap fits into the center hole of the filter and secure tightly. You may use the included wrench (6) if needed. The filter should not move when the housing is shaken.

Screw the short hose (5) fitting with the black plastic adaptor to the right side (outflow) of the housing (4) and secure tightly.

Attach the housing (3) to the hose the water is coming from (Inflow).

Attach the short hose end to the hose coming from the RV/Camper. This is the end the water will come out of the housing. Note: If the hose from the RV does not have a quick connect adaptor, you may need to remove the short hose from the housing and attach it first to the RV hose and then reconnect to the housing.

Turn the water on and the housing will fill up and you will be filling your tanks with purified water.

To install this system as an Undersink Filter System, remove the brass fittings from the housing cap and securely insert the white adaptors (7). You may loosen and tighten the white adaptors to fit the tubing for this installation as needed. Tubing and other parts needed to install this system are not included.

